Continue

Losing or damaging your original TV remote can be incredibly frustrating. Thankfully, a universal remote control offers a powerful and convenient solution to manage all your entertainment devices from a single unit. When talking about universal remotes, RCA universal remote controls are quite popular in the market. Today, we will be taking a look at RCA Universal Remote Codes and detailed, step-by-step instructions on how to program your RCA remote for any device. RCA Universal Remotes are designed to control multiple devices, including TV, DVD, VCR, Cable, Satellite, and other devices. Some models are even capable of controlling up to eight devices. Quick Answer: How to Program Your RCA Universal Remote with Auto-Search Feature Turn on your TV manually. Hold the TV button + Power button together until the red light stays on. Press Play every 5 seconds until the TV turns off. Press Reverse every 2 seconds until the TV turns back on. Press Stop to save the code. Tip: If this method doesn't work, refer to the "How to Program RCA Universal Remote with Codes" section below. Admiral: 0463, 4030, 4111, 4221, 10093, 10463 Advent: 1570, 10761 Affinity: 3717, 3577, 3870 Aiwa: 1362 Akai: 1675, 11675, 10702, 10672 AOC: 1589, 3720, 1365, 2014, 2087, 4101, 11365, 11589, 12014, 12087 Apex Digital: 2397, 4347, 4350, 10156, 10748, 10767, 12397 Ario: 2397 Astar: 11738 Asus: 3340 Atvio: 3638, 3636, 3657 Audiovox: 1564, 1769, 0623, 10451, 10802, 10846, 10875, 11937, 11951, 11952 Auria: 2087, 2014, 2277 Aventura: 0171, 10171 Avol: 3118 Axion: 11937 BGH: 4029, 4070, 0898, 2414, 0876, 4028, 4030 Blue Sky: 3997 Britania: 2414 Broksonic: 0463, 1892, 10463 Carver: 10054 CCE: 3782, 4091, 0623, 4092 Celebrity: 10000 Champion: 1362 Changhong: 3814 Coby: 3478, 3627, 2344, 12306, 12315, 12340, 12343, 12344, 12345, 12347, 12348, 12350 Commercial Solutions: 1447, 11447, 10047 Contex: 4053 Continental: 2357 Coradir: 2844 Craig: 3423 Crosley: 10000, 10054 Crown Mustang: 0898 Curtis: 2855, 3577, 3895, 2352, 2397, 4035, 4053, 3636, 1326, 3382, 3717, 12352 Curtis Mathes: 0623, 10047, 10054, 10451, 10093, 10702, 10145, 11661, 11147, 11347 Cytron: 1326 Daewoo: 0623, 10451, 11661, 10661, 10672 Dell: 11264, 11080, 11863 Denon: 10145 Digitrex: 4207 Dish Network: 11948 Disney: 1892, 0171, 11892, 81017 Dumont: 0017, 10017 Durabrand: 0463, 0171, 1570, 0178, 10463, 10178, 10171, 11034 Dynex: 2049, 2184, 11463, 11785, 11810, 12049, 12184 Electroband: 10000 Electrograph: 11755 Electrohome: 0463, 1570, 1670, 10463 Electron: 2855 Elektra: 0017, 0623 Element: 3559, 1687, 2183, 2964, 1886, 11886, 12183, 01815, 70017, 81918, 45112, 72015, 34211, 79517, 24912, 34611 Elite: 1457 Emerson: .1864, 1394, 0171, 1886, 0463, 1963, 0178, 0623, 3623, 2183, 3559, 11864, 10017, 10451, 10463, 10178, 10171, 11661, 11394, 11944, 11963 Emprex: 11422 Encross: 0876 Envision: 1589, 1365, 2087, 2014, 10813, 11365, 11589, 12014, 12087 Epworth: 1362 EQD: 2014, 2087, 2277 ESA: 0171, 1963, 10171, 11944, 11963 Fair Mate: 1326 Favi: 3382 Fisher: 1362 Fluid: 2964, 3559, 12964, 70013 Fujitsu: 10809 Funai: 1864, 0171, 1394, 1963, 10000, 10171, 11271, 11963 Gateway: 11755, 11756 GE: 1447, 0178, 11447, 10047, 10451, 10178, 11347 GFM: 0171, 1963, 1886, 1864, 10171, 11886, 11963, 12167 Gibraltar: 0017, 10017 Go Video: 10886 GoldStar: 0178, 10178 Haier: 1749, 2309, 1748, 3382, 2293,4398, 1570, 11034, 11748, 11749, 12309 Hallmark: 0178, 10178 Hannspree: 1348, 11348, 11745 Harman/Kardon: 10054 Havermy: 10093 H-Buster: 3620, 3419 Helios: 10865 Hello Kitty: 10451 Hewlett Packard: 11494, 11502 Hisense: 13519, 14740, 14618, 12183, 15156, 15176, 15185, 14656, 11660, 11314, 11756, 13382, 14487, 35611, 44211, 67614, 78115, 59413, 3519, 2183, 4398, 3382, 4029, 10748, 12098, 12355, 12419 Hisense Roku: 44211, 55712 Hitachi: 1643, 3639, 3382, 3697, 11643, 11145, 10679, 10145 Hiteker: 3118 HP: 11494, 11502 Hyundai: 4509 iLo: 0171, 1394, 11394, 11684, 11990 Infinity: 10054 Initial: 11990 Insignia: 12049, 14487, 11780, 13227, 11564, 11326, 12184, 15213, 11892, 12002, 11423, 10171, 10463, 11385, 11660, 12751, 11756, 28911, 12219, 49412, 28511, 06919, 07216, 69212, 89713, 70017, 39512, 45013, 69613, 82615, 61312, 2049, 1564, 1326, 1892, 0171, 0463, 1963, 2184, 11204, 11517, 11810, 11963, 12049, 12417 Insignia Roku: 12219, 44211 Inteq: 0017, 10017 IRT: 0623 iSymphony: 3382, 3118, 3094 JBL: 10054 JCB: 10000 JC Penney: 0178, 0156 JCM: 2256, 12256 Jensen: 1326, 10761 JVC: 1774, 1601, 2321, 2271, 0463, 1570, 1670, 4070, 1892, 10463, 10053, 10731, 11253, 11601, 11774, 12271 KC: 4182 KDS: 1523, 1687, 11498 KLH: 10767 Ken Brown: 4056, 4099, 4221, 4444 Kreisen: 0876 Legend: 2397, 2309 Lexus: 3638, 3657 LG: 31311, 52412, 63913, 11840, 12731, 11860, 11423, 12358, 14397, 14398, 11756, 2731, 2358, 3397, 0178, 0017, 10017, 10178, 10856, 11447, 12424, 11265 LG Alps: 2358 LodgingStar: 3147 LXI: 0156, 0178, 0017, 10047, 10054, 10156, 10178 MAG: 1687, 1523, 11498 Magnavox: 3623, 1866, 2372, 1454, 2597, 1963, 0171, 1365, 1867, 11867, 11454, 10054, 10802, 11198, 11254, 11365, 11944, 11963, 11990, 11866, 12372, 10171, 10051 Marantz: 1454, 11454, 10054 Master-G: 3419 Matsushita: 10250 Maxent: 11755 Megatron: 0178, 10178, 10145 Memorex: 0463, 1570, 1670, 0178, 1892, 0171, 1687, 10463, 10150, 10178, 11892 MGA: 0178, 10178, 10150 Microsonic: 1326, 3419, 4235 Midland: 0017, 10047, 10017, 10051 Mintek: 11990 Miray: 3847, 2414, 2429, 3183, 4178, 0898 Misakai: 0171 Mitsubhishi: 11250, 10093, 10150, 10178, 11797 Mitsubishi Electric: 1250, 0178 Mitsui: .3658, 3638, 3657 Motorola: 10093 NAD: 0156, 0178, 10156, 11156, 10178 Naoki: 1540, 2357 Naxa: 2104, 3382, 3423, 12104, 82318, 11711, 25811, 29419, 41011 NEC: 0876, 2293, 11704, 11797 NetTV: 11755 New Acoustic Dimension: 0156, 0178 Nexus: 3519 Nexus Electronics: 2183, 12183 Nikko: 0178, 0017, 0156, 10178 Nimbro: 2104 Noblex: 1362, 3697, 1142, 4029, 3803, 4030, 4149, 4205 Norcent: 1365, 1589, 10748, 11365, 11589, 11745 Nordmende: 3419, 3861, 3134, 3327, 3767, 3835 NuVision: 4347 Ocosmo: 2337, 3899 Olevia: 1610, 11610, 11144, 11240, 11331 Onn: 14398, 15348, 11709, 11756, 13024, 13078, 15118 Onn Roku: 44211 Optimus: 10250 Optoma: 11348 Optonica: 10093 Orion: 0463, 1892, 3540, 10463, 11463 Panasonic: 1480, 1291, 0156, 0178, 10250, 11480, 11457, 11291, 10051, 11271, 11941, 11946 Panavox: 4149 PARK: 2104, 12104 Penney: 0178, 0156, 10047, 10156, 10178, 11347, 10051 Petters: 11523 Philco: 3426, 3022, 2414, 0171, 1963, 4178, 0623, 1394, 1142, 1362, 0463, 3639, 3697, 10054, 10171, 11271, 11394, 11963 Philips: 11867, 12372, 11454, 12374, 11866, 13623, 14365, 14398, 10054, 10171, 11755, 11365, 11394, 11756, 14740, 62414, 17419, 33412, 06918, 73915, 84416, 95017, 44211, 21319, 43911, 48111, 82615, 88518, 1867, 2372, 1454, 2597, 4222, 3623, 2800, 1744, 1866, 0017, 0171, 1963, 1365, 1394, 1589, 10690 Philips Roku: 44211 Pioneer: 1457, 11457, 10679, 11260 Planar: 1589, 11589, 40413, 75812 Polaroid: 1523, 1769, 4035, 1687, 1326, 1524, 11523, 10865, 11276, 11314, 11498, 11766, 12002, 12121 Portland: 0623, 10451, 11661 Prima: 1749, 10761, 11749, 11785 Proscan: 1447, 3577, 3382, 2183, 2256, 3717, 3332, 3636, 3895, 4035, 4053, 4483, 4495, 2746, 3559, 3953, 11447, 10047, 11347, 12147, 12183, 12256 Proton: 0178, 10178 Proview: 1687, 1523, 11498 Pulsar: 0017, 10017 QuantumFX: 2337 Quasar: 3899, 4207, 4367, 1291, 10250, 11291, 10051 RadioShack: 0178, 10178, 10047 RCA: 2746, 2932, 2434, 3577, 1447, 2247, 3382, 3717, 3332, 3895, 2187, 4053, 3636, 2183, 2855, 3147, 4394, 0623, 2429, 3419, 4035, 1670, 11547, 11447, 10047, 10093, 10679, 11047, 11147, 11247, 11347, 11781, 11948, 11953, 12002, 12187, 12434, 12746, 10051, 11661, 12247, 12932 RCA Roku TV: 44211 Realistic: 0178, 10178 Recco: 3847, 0898, 3183 Roku: 14398, 14740, 14487, 11756 Runco: 0017, 10017 Sampo: 11755 Samsung: 12051, 11632, 15386, 15371, 21818, 97817, 77114, 79113, 16616, 36218, 66611, 2051, 3993, 0178, 10702, 10178, 11060 Sankey: 2964 Sansai: 4030 Sansui: 3540, 0463, 1892, 1670, 3564, 4053, 0171, 3559, 10171, 10463, 11409, 11892 Sanyo: 11142, 14168, 14740, 12049, 13488, 11480, 10054, 11564, 11756, 33711, 03818, 10811, 98718, 77715, 88513, 99014, 1142, 1362, 3697, 3861, 1480 Sceptre: 3899, 2528, 2337, 11360, 11599, 12337, 12506 Scotch: 0178, 10178 Scott: 0178, 10178, 11711 Sears: 0156, 0171, 0178, 10047, 10054, 10156, 10178, 10171 Seiki: 3953, 2964, 3559, 3382, 3560, 0178 Semp Toshiba: 1743, 3793, 0156 Sens: 1749 Sense: 11865 Serie Dorada: 3814, 4221 Sharp: 12360, 14618, 14740, 11659, 13519, 13394, 15156, 12402, 14507, 15176, 11756, 14398, 35611, 31713, 91517, 02118, 13019, 37311, 50912, 2360, 3720, 1457, 4398, 10093, 10818 Sharp Roku TV: 55712, 13019 Sheng Chia: 10093 Sherwood: 11399 Sigmac: 3477, 3423 Silo: 3899, 3477, 4182 Sony: 10810, 12778, 14448, 14189, 31912, 89616, 41112, 0810, 10000, 11300 Soundesign: 0178, 10178 Sova: 11952 Soyo: 11520, 11826 Spectroniq: 1523, 1687, 11498 Speler: 4105, 4041 Squareview: 0171, 10171 STI: 3793 SunBriteTV: 2337, 1610, 2528, 11610, 12337 Superscan: 1963, 0171, 10093, 10864, 11944 Supersonic: 2104, 12104, 25811, 41811, 01117, 88715, 44711, 46911 Supreme: 10000 Suzuki: 4434 SVA: 1963, 10748, 10865, 11963 Sylvania: 1864, 1886, 0171, 1963, 1394, 11864, 10054, 11394, 10171, 11271, 11314, 11886, 11944, 11963 Symphonic: 0171, 1963, 1394, 11394, 10171, 11944 Syntax: 1610, 11610, 11144, 11240, 11331 SZK: 4434 Taki: 1540 Tandy: 10093 Tatung: 11756 TCL: 14398, 12434, 13183, 11756, 80313, 36711, 57513, 15919, 68014, 37511, 61513, 44411, 44211, 80312, 2434, 4398, 3183, 2429, 3426, 3847, 2414, 0898, 4178, 26245, 78913, 84416, 33012, 95017, 57011, 6918, 36711, 61514 TCL Roku: 44211 Technics: 0017, 10250, 10051 Techview: 10847 Techwood: 10051 Teknika: 10054, 10150 Telefunken: 2414, 4025, 4302, 10702 TMK: 0178, 10178 TNCi: 0017, 10017 Tonomac: 4221, 4444 Tosaki: 1540, 2357 Toshiba: 11524, 11656, 12724, 15213, 14885, 10156, 67611, 36911, 48512, 36411, 65014, 70017, 70416, 08318, 72014, 90616, 78614, 24919, 57812, 1524, 1656, 0156, 3134, 1743, 11156, 11256, 12006, 11265, 10845, 11704, 11945, 11356 Trutech: 0171, 11723 TVS: 0463, 10463 UpStar: 4182, 4405 Venturer: 11865 Victor: 10053 Vidikron: 10054 Vidtech: 0178, 10178 Viewsonic: 2014, 2745, 2087, 1627, 2049, 2277, 1564, 1365, 12049, 10864, 11564, 10885, 11330, 11365, 11578, 11627, 11742, 12014, 12087, 11755, 10857 Viore: 2352, 3382, 3118, 2104, 3094, 11684, 12104, 12352, 13118 Vizio: 11758, 13758, 14905, 14723, 12707, 12757, 12512, 11756, 35011, 40412, 80016, 20111, 1758, 3758, 2707, 2757, 10864, 10885 Wards: 0178, 0017, 0156, 10156, 11156, 0178, 10047, 10017, 10051, 11347, 10054 Waycon: 0156, 10156 Westinghouse: 1712, 3559, 3382, 2293, 3094, 3470, 2397, 0463, 11712, 10451, 10885, 10889, 11282, 11300, 11577 White Westinghouse: 0623, 0463, 10463, 11661 Wyse: 1365, 11365 Xoceco: 1749 Zenith: 0017, 0178, 0623, 2731, 1365, 2358, 0463, 10000, 11423, 12358, 12731, 10178, 10047,10017, 10463, 11265, 11145, 11661, 11365, 10145 TV BrandCode TypeCodesLG TV4-Digit Code2731, 2358, 3397, 0178, 0017, 1423, 1447, 2424, 1178, 1265, 0856, 19345-Digit Code11423, 10017, 10178, 10856, 11447, 12358, 12424, 12731, 11265, 11136, 11565, 21442, 25641, 31462, 31311, 52412, 63913, 38312, 47312, 58813, 11840, 11860, 14397, 14398, 11756Samsung TV4-Digit Code2051, 3993, 0178, 0702, 0650, 0030, 0766, 08145-Digit Code10702, 10178, 11060, 12051, 11251, 11565, 14241, 14425, 14545, 24366, 21818, 97817, 77114, 79113, 16616, 36218, 66611, 43311, 94818, 38811, 11632, 15386, 15371Hisense TV4-Digit Code3519, 2183, 4398, 3382, 4029, 1314, 1660, 2098, 23555-Digit Code13519, 14740, 14618, 12183, 15156, 15176, 15185, 14656, 11660, 11314, 11756, 13382, 14487, 35611, 44211, 67614, 78115, 59413, 10748, 12098, 12355, 12419, 14355, 24525, 25146, 39812, 61514, 31612, 42113, 39011Hisense Roku TV35611, 44211, 55712, 67614, 78115, 59413, 61514, 72015Insignia TV4-Digit Code2049, 1564, 1326, 1892, 0171, 0463, 1963, 2184, 1423, 0171, 1517, 1660, 1785, 2417, 27515-Digit Code12049, 14487, 11780, 13227, 11564, 11326, 12184, 15213, 11892, 12002, 11423, 10171, 10463, 11385, 11660, 12751, 11756, 28911, 12219, 49412, 28511, 06919, 07216, 69212, 89713, 70017, 39512, 45013, 69613, 82615, 61312, 11204, 11517, 11810, 11963, 12049, 12417, 11554, 13162, 21442, 22116, 22235, 22641, 23244, 23543, 24142, 24245, 24364, 25151, 26216, 33646, 68515, 22011, 57513, 47913, 36412, 40211, 64713, 56111, 79016, 21711, 74115, 41011, 73114Sony TV4-Digit Code0810, 1300, 1317, 16855-Digit Code31912, 89616, 41112, 10000, 10810, 12778, 14448, 14189, 11300, 14541, 21115, 22556, 26411, 44613, 33211, 44411, 44211TCL TV4-Digit Code2434, 4398, 3183, 2429, 3426, 3847, 2414, 0898, 4178, 69185-Digit Code14398, 12434, 13183, 11756, 80313, 36711, 57513, 15919, 68014, 37511, 61513, 44411, 44211, 80312, 26245, 78913, 84416, 33012, 95017, 57011, 36711, 61514TCL Roku TV44211, 61514Vizio TV4-Digit Code1758, 3758, 2707, 2757, 0864, 1756, 08855-Digit Code11758, 13758, 14905, 14723, 12707, 12757, 35011, 40412, 80016, 20111, 12512, 11756, 10864, 10885, 15111, 15144, 23155, 23161, 26455, 31544, 36333, 13415, 22111, 28911, 51914, 34112, 14905, 14723 American High 0035 Canon 0035 Carver 0081 Crosley 0081 Curtis Mathes 0035, 0060, 0162 Daewoo 0045 Emerex 0032 Fuji 0035 GE 0060, 0035, 0202 Harman/Kardon 0081 Instant Replay 0035 JC Penney 0035 Kodak 0035 Magnavox 0035, 0081 Marantz 0081, 0035 Matsushita 0035, 0162 MEI 0035 Memorex 0035, 0162 Motorola 0035 NAP 0035 Olympus 0035 Optimus 0162 Panasonic 0035, 0162 Penney 0035 Philco 0035 Philips 0081, 0035 Polk Audio 0081 Proscan 0060, 0202 Quasar 0035, 0162 RCA 0060, 0202, 0035 RCN 0060 Realistic 0035 Samsung 0045 Scott 0045 Sears 0035 Semp Toshiba 0045 Signature 0035 Signature 2000, 0035 Sony 0032, 0035 Sylvania 0035, 0081 Technics 0035, 0162, 0060, 0202 Teknika 0035 Toshiba 0045 Vector 0045 Video Concepts 0045 Wards 0035, 0045, 0060, 0081 XR-1000 0035 Arion 1279, 4348 Arris 0869 AZ America 3599 Bell 0775 Bell ExpressVu 0775 Bell Satellite TV 0775 Century 0856 Claro 4546, 3790 Coship 4546, 3790 DirecTV 1377, 1442 Dish Mexico 0775 Dish Network 0775 Dishpro 0775 Echostar 0775, 2262, 2527 Embratel 4546 Frontier Communications 0775 General Instrument .0869 GOI 0775 Gradiente 0887, 0856 GVT 3789 HTS 0775 Huawei 4546 Hughes Network Systems 1442, 1377 Humax 1377 Intv 4348 Jerrold 0869 JVC 0775 LG 1377 Motorola 0869, 0856, 3469 Movistar 2527, 2262 Nagra 2262 Netgem 3637 Netsat 0887 Next Level 0869 Oi TV 4460 Pace 0887, 3469, 1377, 2895, 3111, 3790, 4546 Philips 1442, 2619, 0856, 0887, 3469 RadioShack 0869 RCA 1442 Sagem 1692 Sagemcom 3789 Samsung 1442, 1377 Shaw Direct 0869, 0775 Sky Brasil 1377, 0887, 0856, 2619, 3111 Sky Mexico 3469, 2619, 0856, 0887, 1377 Star 0887 Star Choice 0869 Supernova 0887 TDS Telecom 0775 Technicolor 3790, 3469 Tele Red 1279 Telefonica 1692, 2262, 2527 Televisa 0887 TELUS 0775 Thomson 3469, 1377, 2619 TiVo 1377, 1442 TVA Digital 2895, 1692, 2262 UNE 1692 Via Embratel 4546 Vivo 2262, 2895, 1692, 2527 Windstream 0775 Zenith 0856, 3469 Access Communications 1376, 2187 Adams Cable TV 1376, 4079 ADB 2254, 1481, 1998, 2302, 3028 Allegiance Communications 1376 Amino 1615, 1481, 2482, 1998, 2302, 3028 Arion 3336 Armstrong 1376, 3560 Arris 1376, 1998, 2187, 1982 Arvig Communication Systems 1376, 1982, 1998, 3028 AT&T 0858, 1877, 2187 AT&T U-verse 0858, 1877, 2187 Atlantic Broadband 1877, 3560, 1376, 4079 ATMC 1376, 1982, 3028, 1998 Bell 1998, 1877 Bell Aliant 1998 Bell Fibe TV 1998 Blue Ridge Communications 1877, 3560 Bright House 1877, 1376, 3294 Broadstripe 1376 Buckeye Cable System 1376, 2187, 1877 Cable America 1376, 1877 Cable Axion Digitel 1376 Cable One 1376, 3560, 1877 Cablecom Mexico 1376 Cablem·s 3119, 1376, 1877 Cablevision 1376, 1877, 3336, 4375 Cablevision du Nord 1376 Cablevision Victoria 1376, 4375 Cass Cable 1376 CCAP 1877 CenturyLink 1998 Channel Master 3118 Charter 1376, 1877, 2187, 3560 Choice Cable TV 1376, 1877, 1982 Cincinnati Bell 1877, 1376 Cisco 1877, 3028, 0858, 1982, 1883, 2506, 1376, 4374, 4514, 2826, 3294, 4450 Claro 1376, 1998, 3028 Cogeco 1376, 1982, 3560 Comcast 1982, 1376, 1877, 3560, 2187 Comporium 1877, 3560, 2187 Consolidated Communications 1877, 1376, 1998, 2302, 3048 Convenient 3527 Cox 1877, 1376, 3774, 4315 Digeo 2187 Eagle Communications 1376, 2187 EastLink 1376, 2187 Echostar 3452, 3454 Entone 3048, 2302, 1615 Evolution 2479, 4079, 2746, 4315 Fidelity Communications 1376 Frontier Communications 1376 General Communications 3560, 1376, 1877 Google 3666 Grande Communications 1877, 3560, 1376 Great Plains Communications 1376 Hawaiian Telcom 3028 Huawei 4589, 1982, 4883 Humax 3560 Inter Mountain Cable 1877, 2479, 4079, 2826, 3294 Izzi Telecom 1376 Kathrein 3288 LG 4343 Liberty Cablevision 1376 Lumos Networks 1998, 3028 Massillon Cable 1376, 2187 Maxcom 1998 Mediacom 1376, 3560, 1982, 1877 Mediastream 1376 Megacable 1376, 4374, 4450, 4514, 2506, 4375, 4883 Megaseñal 3527 MetroCast Cablevision 1376, 1982, 1877 Mi-Connection 1877 Midcontinent Communications 1376, 1982, 3560, 2826, 4079 Mid-Hudson Cable 1376 Motorola 1376, 1998, 0858, 1982, 4375 Movistar 3288 Moxi 2187 MTS 1998 NET 1883 Netgem 4634 NewWave Communications 1376, 2187 Northland Communications 1376 NU Telecom 1998, 3028 Oi TV 3454, 3452 Optimum 1877 Pace 1376, 1982, 1877, 3454, 0858, 1883, 3560, 1998 Panasonic 1982 Philips 1376, 3560 Pioneer 1877 RCN 1376, 3560, 1877 Reach Broadband 1376, 1877, 1982 Rogers 1877, 1376, 2826, 3294 Sagem 3288 Sagemcom 3288 Samsung 1877, 3928, 1982 SaskTel 1998, 1737 Schurz Communications 1376, 1877, 1982 Scientific Atlanta 1877, 0858, 3028, 1982, 1376, 2826 Service Electric 1376, 1982, 1877, 2187 Shaw 1376, 1877, 2187, 1982 Shentel 1376, 1877, 1982, 2187 Sogetel 1998, 2482 Source Cable 1376 Suddenlink 1877, 1376, 3560, 1982 Supercanal 1376 Tbaytel 1998 TDS 1376, 1877, 1982 Technicolor 1982, 3288, 3454 TeleCable 1376 Telecentro 1376 Telefonica 3028, 3288 Telmex 1376 TELUS 3028 Thomson 1982 Time Warner 1877, 1376, 2187, 3294 TiVo 3560 Totalplay 4634, 4589, 4591 TV Cable 1376 TVS Cable 1376, 1877, 1982 UNE 2506 U-verse 0858, 1877, 2187 Verizon 1376 Vidéotron 1877, 1376 Vivo 3288 VTR 1376 Wave Broadband 1376, 2479, 3560, 4079, 2187 Wavevision 1376, 1877, 1982 WEHCO Video 1376 Westman Communications 1376, 2187 WideOpenWest 1376, 1877, 2187 Windjammer Cable 1376, 1877 WNC 3118 WOW! 1877, 1376, 2187, 2479, 2826, 3294 Xfinity 1982, 1376, 1877, 3560, 2187 Zito Media 1376, 1877, 1982 Z-Trak 1376 Accurian 0675 California Audio Labs 0490 Curtis Mathes 2331 Denon 1634, 2258, 0490 Disney 0675 Durabrand 3464 Dynex 2596 Emerson 0675, 2213 Funai 0675 GE 0522 General Electric 0522 GFM 0675 Go Video 1075, 0741 GoldStar 0741 Grundig 0539 Hitachi 0573, 0675 HitPlus 2583 Insignia 2596, 2095, 2428, 0675, 0741 Integra 2147, 1634 JVC 0741 Kenwood 0490 Lenoxx 2213 LG 0741 Magnavox 0675, 0503, 0539 Marantz 0539 Memorex 2213, 2331 Microsoft 2083, 2627, 0522 NAD 0741 New Acoustic Dimension 0741 Olevia 2331 Onkyo 2147, 0503 Panasonic 1641, 3641, 0490, 0503 Philco 0675 Philips 2056, 2434, 0539, 0503, 2084, 0675 Pioneer 2442 Polk Audio 0539 Presidian 0675 Proscan 0522 RCA 0522, 2587, 2213, 2532, 3464 Samsung 0199, 0573, 1075, 2069, 2489, 0490 Semp Toshiba 0503 Sharp 2250, 0675 Shinsonic 0533 Sony 1516, 1633, 0533, 0864, 1070 SV2000 0675 Sylvania 0675 Symphonic 0675 TCL 2587 Technics 0490 Toshiba 0503, 2277, 3157, 2705 TruTech 0675 Urban Concepts 0503 VIZIO 2563 Vtrek 2583, 2587 Xbox 2083, 2627, 0522 Yamaha 2298, 0539, 0490 Zenith 0741, 0503 Access HD 2185 Alpha Digital 2185 AMTC 2185 Centronics 2360 Channel Master 2360 Digiwave 2360 Dish Network 2470 Echostar 2470 Firebird Systems 2360 GE 2360 General Electric 2360 Goodmind 2360 iNet Access 2185 Insignia 1415 LG 1415 RTC 2360 Tivax 2185 Zenith 1415 Universal remotes come with support for more than one device. So you might also be looking to program the remote for other electronic devices like DVDs, Consoles, and more. Also if you want a printable code list, then you can download a printable file from the link below. Download Printable RCA Remote Codes Now that you have access to RCA remote codes, its time for the program guide. You can follow the without codes method if you didn't find your device on the list. No matter what RCA Universal Remote Control you have, the steps to program the remote to your TV will be the same. The same can be said regardless of the TV brand that you plan to use the RCA Universal Remote with. Before moving to the steps, note down the codes you will need for your particular TV brand. We have listed all the control codes below. Or you can check the manual received with your Remote. Step 1: Insert batteries in your RCA remote. Also, power up your TV. Step 2: Press and hold the TV key on your remote while pointing the remote towards the TV. Or press and hold another device key if you want to connect another device like Cable, DVD, etc. Step 3: Release the device key once the power key on the remote light up. Step 4: While the Power button is lit, enter the pairing code for your device from the list. Step 5: When you enter the correct code, Power key light will turn off. Once programmed, test the remote functions with your device. If the power button led blinks twice, this means you have entered the incorrect code. So try the second code and other codes as well until the power button turns off. Step 1: Power On your TV. Point the Remote towards TV/device for the whole process. Step 2: Press and hold the TV key. Hold the specific device key if you are programming it for another device (like DVD, VCR). Step 3: While holding TV key, also press and hold the Power key. The power key or LED indicator will turn on. Now you can release both keys. Step 4: While pointing the remote to TV, Press the Play key and wait for 5 seconds. If TV/device turns off move to next step. If not, press the Play key again and wait 5 seconds. Repeat the process until your device turns off. Step 5: Once your TV turns off, press the Reverse key and wait for at least 2 seconds. If your TV/device turns on, move to next step. If not, press the Reverse key and repeat the process. Step 6: When your TV/device turns back On, immediately press the Stop key to save the code. Now your RCA remote is programmed and you can test the remote. Check if the basic functions such as power volume, channel, menu, and source buttons are working perfectly or not. Step 1: Make sure your device is turned on and you are aiming the remote towards the device. Press and hold the Code Search key on your Remote until the indicator light turns on. Step 2: Now press and release the device key, e.g. TV key if you are programming for your TV. Step 3: Enter the code manually. You can check the codes from the list above or from the manual you have received with your Remote. Step 4: After entering the correct code, the indicator light will turn off. Now you can test your Remote with your device. If the indicator light flashes twice after entering a code, this means the code is incorrect. Then you can try other codes. Step 1: Turn on your TV or other device that you want to program with RCA Remote. Point the Remote towards the device for the process. Step 2: Press and hold the Code Search Key until the LED turns on. Step 3: Press and release the Device key, for example TV key if you are programming for TV. The indicator light will blink once and stay lit. Step 4: Now press and release the Power key until your device turn off. You might need to press the key up to 200 times. Step 5: When your device turn off, immediately press the Enter key (within 4 seconds) to save the code and the indicator LED will turn off. There are various RCA universal remote models to choose from. Here are currently available RCA Universal Remote Controls. 2-Device and 3-Device RCA Remote Controllers RCR313BE RCR3273E RCR503BE RCRH02BE RCRN03BE 4-Device and 5-Device RCA Remote Controllers RCR414BHE RCR504BE RCRBB04GBE RCRBB05BHE RCRBB05BHZ RCRN04GBE RCRPST04BE RCRPST05SE RCRTBL04BE 6-Device and 8-Devices RCA Remote Controllers RCR6473E RCRN06GBE RCRPST06GBE RCRTBL06BE This concludes the guide on how you can pair and program an RCA universal Remote with any TV brand that you own. With such remote codes, you can make use of a universal remote easily. So, the next time you lose a TV remote, always be assured that the RCA Remote is there to save you. If you have questions or queries, feel free to leave them in the comments section below. Related Articles: Last Updated on August 14, 2020 by Randall Have you just bought a Vizio Sound Bar? It's one of the familiar Sound Bars in the market. Usually, it comes with a remote control but if for any reason you lost your original remote code, just go for a new Vizio Sound Bar Remote Codes. We provided below the full list of Vizio Sound Bar remote code, however you'll need to know how to program it which we have also made for you, it's a simple process you have just to follow our steps with all explanations. Read also: Ilive Sound Bar Remote Codes Turn on your Vizio Sound BarGo now to Settings and then programs.Choose Sound optionNow the tiny light will blink 4 times.Go to the list above and choose any of the codes and enter it.To make sure everything is good press on any of the buttons on your remote. Check also: Sanyo Sound bar Remote Codes For more explanation you can watch this video: Sometimes but not always the remote control that comes with the sound bar is a universal remote. There are currently available RCA Universal Remote Controls. 2-Device and 3-Device RCA Remote Controllers RCR313BE RCR3273E RCR503BE RCRH02BE RCRN03BE 4-Device and 5-Device RCA Remote Controllers RCR414BHE RCR504BE RCRBB04GBE RCRBB05BHE RCRBB05BHZ RCRN04GBE RCRPST04BE RCRPST05SE RCRTBL04BE 6-Device and 8-Devices RCA Remote Controllers RCR6473E RCRN06GBE RCRPST06GBE RCRTBL06BE This concludes the guide on how you can pair and program an RCA universal Remote with any TV brand that you own. With such remote codes, you can make use of a universal remote easily. So, the next time you lose a TV remote, always be assured that the RCA Remote is there to save you. If you have questions or queries, feel free to leave them in the comments section below. Related Articles: Last Updated on August 14, 2020 by Randall Have you just bought a Vizio Sound Bar? It's one of the familiar Sound Bars in the market. Usually, it comes with a remote control but if for any reason you lost your original remote code, just go for a new Vizio Sound Bar Remote Codes. We provided below the full list of Vizio Sound Bar remote code, however you'll need to know how to program it which we have also made for you, it's a simple process you have just to follow our steps with all explanations. Read also: Ilive Sound Bar Remote Codes Turn on your Vizio Sound BarGo now to Settings and then programs.Choose Sound optionNow the tiny light will blink 4 times.Go to the list above and choose any of the codes and enter it.To make sure everything is good press on any of the buttons on your remote. Check also: Sanyo Sound bar Remote Codes For more explanation you can watch this video: Sometimes but not always the remote control that comes with the sound bar is a universal remote, so to be sure about it just check if it has the 'Set' and 'Mode' options, if so that's mean it's a universal remote control. As an Amazon Associate we earn from qualifying purchases made on our website. Are you tired of juggling multiple remotes just to watch TV? Using a universal remote to control your soundbar with ease is a great convenience. Say goodbye to the hassle of managing different controllers and dive into the simplicity of consolidating your controls into one device. You can use a universal remote to control your soundbar. Several solutions can fix this. Some use IR technology to communicate, while others rely on hardwired connections like HDMI ARC or a Digital Fiber Optical Cable to simplify controls. In this article, explore how to sync your soundbar with a universal remote, whether through IR technology or hardwired connections like HDMI ARC or Digital Fiber Optical Cable. Learn the steps, from decoding binary data to programming brand-specific pairing codes, to streamline your home entertainment setup effortlessly. Most soundbars (by the way, we have a Top 8 List here) will allow you to control them using a universal remote, but this will depend on the type of soundbar you have. To make this work, your soundbar will have to have an IR (Infrared) sensor equipped. IR uses waves to transfer binary data in pulses over the electromagnetic spectrum. For both devices to communicate, the receiving equipment needs to be able to decode this data. IR technology, commonly used in remote controls, is popular for relaying basic command functions. While it has various applications, for most consumers, its primary use lies in controlling electronics like TVs. This requires a few components. IR Sender/Blaster – This will be on the remote itself IR Receiver – Located on the soundbar IR Decoder – This will use control protocols like RC-5 or SIRC to decode the binary message to command the soundbar to move the volume up or down. If your soundbar has an IR receiver, chances are you will be able to control it with a little setup. Here are a few soundbars on Amazon that allow for IR communication: the Sonos Playbar, Samsung HW-Q60T, and the Vizio 2.1 Soundbar. We also have a guide on using universal remotes with a Sonos soundbar. If your soundbar comes with a remote, it likely uses IR technology for communication, allowing compatibility with a universal remote. However, you'll need to set it up by programming brand-specific pairing codes into the remote for most cases. Pairing a universal remote with a soundbar is generally straightforward, but instructions vary by brand. With the right universal remote codes for pairing and a bit of time, you can control your sound bar using your remote. Let's look at some general steps to get started. Find the 3, 4, or 5-digit pairing code for your soundbar (common ones listed below). Ensure both your TV and soundbar are powered on. Point your universal remote at the soundbar you want to pair to. Press the Setup button on your universal remote until the light flashes (this step varies by brand), or press the AUX and OK buttons simultaneously, then press the channel up button. Hold until the soundbar turns off, then press the AUX button again to save (if successful, setup is complete). Enter the brand-specific pairing code into the universal remote. Look for the indicator light on the remote to flash, indicating successful pairing. Test your remote by adjusting the volume to ensure everything works correctly. This setup sequence provides a general guideline. Refer to your universal remote's user manual for specific instructions as setups may vary. The crucial step is obtaining the correct soundbar pairing codes, which are brand-specific. Below are some codes for popular brands. BoseInsigniaSamsungSonyLGVizio40012126832609134532676088350421200222609402911993066040171046321014317593195315171961200453129311443162931517312291114431841319753063931253306 74Common Soundbar Universal Remote Pairing Codes By Brand Depending on the connectivity options on the soundbar, you may be able to use the stock TV remote to control the volume, instead of the soundbar remote. This method will require you to have an HDMI ARC input on your soundbar and an HDMI ARC port on your TV. This method is straightforward, and we have another guide on how to control a soundbar with a TV remote that you should check out, but the basic steps are: Find the HDMI ARC connection on both the soundbar and TV. Connect an HDMI cable to each. Turn the TV and soundbar on. Test and troubleshoot any connection issues. If it is not working, try enabling the CEC option on your TV. In this setup, remember that both the TV and soundbar have separate volume controls. Even if the TV volume is high, the soundbar may remain quiet if its volume is low or on mute. This scenario is similar to using a wireless speaker with a device or using a Firestick remote to control the soundbar. To optimize sound from your soundbar, adjust settings carefully to avoid low volume or audio distortion from being too high. Ensure correct audio output settings on both your TV and soundbar